

H-TEN BB TENOR SAX BRASS-SAVER

The brass-saver is suitable for cleaning Bb Tenor Sax. Handy and practical, it helps to remove all impurities. Used regularly it allows you to maintain the quality. Washable with function draws moisture.



PRODUCT DETAILS

KEY FEATURES

Very soft bristles that do not scratch the instrument

Washable

Function De-Moisturizer