

7706500000

2-BUTTON FOOTSWITCH ACOUSTIC PRO/SFX® BLACK

Restore your contemporary Fender® amp's footswitch functionality with a genuine replacement Fender footswitch.



7706500000

2-BUTTON FOOTSWITCH ACOUSTIC PRO/SFX® BLACK

PRODUCT DETAILS

KEY FEATURES

12' cable with 1/4" plugs

Used for Acoustic Pro and Acoustic SFX® amplifiers

Connection Type: 1/4"

Style: Modern