

H-TBB BELL BRUSH FOR TENOR SAXOPHONE

The products HW Pad-SAVER® and HW Brass-SAVER® are designed to maintain easily and effectively your instrument clean, safe and ready to play



PRODUCT DETAILS

KEY FEATURES

Bell brush for tenor saxophone

Washable

Function De-Moisturizer