

7706500000

# 2-BUTTON FOOTSWITCH ACOUSTIC PRO/SFX® BLACK

Restore your contemporary Fender® amp's footswitch functionality with a genuine replacement Fender footswitch.

7706500000 and or type unknown

VGMHrJ5JD7o8A8F7npE8hJskZMLU32h7YQHntFgN.jpeg

UXEqt5NtAUk7a9yr4zMQfJKLnTQjOMGDo3Tr.jpeg

## PRODUCT DETAILS

### KEY FEATURES

12' cable with 1/4" plugs

Used for Acoustic Pro and Acoustic SFX® amplifiers

Connection Type: 1/4"

Style: Modern