

CC30-RC

# FOOTSWITCH FOR CAMDEN-30 AND CAMDEN 30-H

Footswitch for CAMDEN-30/CAMDEN 30-H with cable (reverb and channel selection control)

CC30-RC found or type unknown

## PRODUCT DETAILS

### KEY FEATURES

Metal chassis

Switches: 2